



## BUR (BUILT UP ROOF) FLAT TOP VENT INSTALLATION INSTRUCTIONS

**Important: Read Instructions Before Installation.**

1. Be certain that the hole in the roof deck is sized appropriately for the BUR. The hole in the roof deck should be the same as the dimensions of the opening of the BUR base.
2. If installing on an existing roof, remove any debris or materials that may prevent the BUR flange from laying flush against the roof deck.
3. Place the BUR over the vent hole ensuring that metal flange is flush with the roof surface.
4. Secure the BUR flange to the roof deck. The flashing flange must be secured to the roof deck by using an adequate application of round head fasteners into solid substrate. Fastening evenly spaced, 1" from edge of flange is optimal.
5. Follow the roofing system manufacturer's installation instructions to install and flash the roofing membrane to BUR flange.
6. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at [www.menzies-metal.com](http://www.menzies-metal.com) or scan the QR code.



**Menzies Metal Products**

**More Than Just Metal**

19370 60<sup>th</sup> Avenue, Surrey, BC V3S 3M2  
800-665-8840 sales@menzies-metal.com  
www.menzies-metal.com

E. & O.E  
01242014