



GOOSENECK VENT INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

FLAT ROOF - Installation for Pitch 2 1/2 Minimum to 3/12 Maximum

1. Determine the size of the hole required. The hole in the roof deck should be the same size as the opening of the base of the Gooseneck.
2. Cut the hole in the roof deck.
3. Remove any debris or materials that may prevent the Gooseneck flange from laying flush against deck.
4. Place the Gooseneck Vent on the roof deck ensuring that metal flange is flush with roof surface. The flashing flange must be secured to the roof deck by using a minimum of 4 round head fasteners into solid substrate evenly spaced, 1" from edge of flange is optimal.
5. Follow roofing system manufacturer's installation instructions for installing and flashing roofing membrane to Gooseneck Vent.
6. Adhere to the installation requirements as determined by the regulatory authorities for your region.

STEEP ROOF - Installation for Pitch Over 3/12

1. Determine the size of the hole required. The hole in the roof deck should match the size of the opening in the base of the Gooseneck.
2. Remove any nails that will prevent the vent flange from sliding into place under the shingles.
3. Cut the hole in the roof deck.
4. Slide the vent under shingles. Flash into shingles using proper roofing practices. The exposed flange should lay on top of the shingles as shown; as if the flange were a shingle.
5. Adhere to installation requirements as determined by the regulatory authorities for your region.



Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzies Metal Products

19370 60th Avenue, Surrey, BC V3S 3M2
800-665-8840 sales@menzies-metal.com
www.menzies-metal.com

More Than Just Metal

E. & O.E
01242014