



SPUN ALUMINUM B-VENT INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

1. Be certain that the hole in roof deck matches the opening in the bottom of the B-Vent.
2. If installing on an existing roof, remove debris or materials that may prevent the B-Vent flange from laying flush against the deck.
3. Place the B-Vent on the roof deck ensuring that the flange is flush with deck.
4. The flashing flange must be secured to the roof deck using a minimum of 4 round head fasteners into solid substrate. Fastening evenly spaced, 1" from edge of flange is optimal.
5. Follow roofing system manufacturer's installation instructions for installing and flashing roofing material to B-Vent.
6. Seal the flashing to the pipe with an appropriate storm collar and sealant.
7. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Visit the Menzie's Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzies Metal Products

19370 60th Avenue, Surrey, BC V3S 3M2
800-665-8840 sales@menzies-metal.com
www.menzies-metal.com

More Than Just Metal

E. & O.E
01242014