



## SPUN COPPER DECK DRAIN NO HUB INSTALLATION INSTRUCTIONS

1. Cut an appropriate sized hole over the receiving drainpipe.
2. Remove any debris or material that may prevent the drain flange from laying flush on the deck.
3. Remove the strainer from the drain.
4. The flange must lay flush on deck. Secure the drain to the deck with a minimum of 3 broad-head fasteners.
5. Make certain decking material reaches the edge of drain bowl but does not go into the drain bowl.
6. Apply and secure the roofing material according to the manufacturer's instructions.
7. Replace the strainer and tighten securely.
8. Under deck connection is by others.
9. Adhere to installation requirements as determined by the regulatory authorities for your region.