



VANDALPROOF CAP INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

1. Slide the cap over the pipe flashing until seated.
2. Drill 3 evenly spaced holes into both the cap and the flashing. Do not penetrate the pipe.
3. Install rivets into all 3 holes.
4. Check to ensure that the cap is secured to the flashing.
5. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Before installing TPO refer to membrane manufacturers instructions.

Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzies Metal Products

19370 60th Avenue, Surrey, BC V3S 3M2
800-665-8840 sales@menzies-metal.com
www.menzies-metal.com

More Than Just Metal

E. & O.E
01242014