



8" METAL ROOF STEM VENT (FOR STEEP ROOF) INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

1. Prior to cutting the hole, ensure that there are no obstructions or trusses beneath the new vent location. A minimum clearance of 8" x 8" is required.
2. Mark the center of the vent location with a screw to locate it easily on the roof.
3. With the screw as the center mark, outline an 8" x 8" square on the roof.
4. Cut the hole.
5. Remove any nails that will prevent the vent flange from sliding into place under the shingles.
6. Slide the vent under shingles. The exposed flange should lay on top of the shingles as shown; as if the flange were a shingle.
7. Screw or nail the vent into place.
8. Secure shingles if required.
9. If making the connection to the vent pipe from under the roof, secure the vent pipe to the roof vent.
10. Adhere to installation requirements as determined by the regulatory authorities of your region.



Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzies Metal Products

19370 60th Avenue, Surrey, BC V3S 3M2
800-665-8840 sales@menzies-metal.com
www.menzies-metal.com

More Than Just Metal

E. & O.E
01242014