



CLAMP-TITE OVERFLOW SCUPPER DRAIN INSTALLATION INSTRUCTIONS

1. Prepare a hole in the parapet wall that is slightly larger than the drain exit pipe.
2. Insert the drain into the hole so that the flange is flush with the wall.
3. Check to see that the drainpipe extends beyond the parapet wall a minimum 2".
4. Fasten the flange with a minimum of 4 broad-head screws, 1" in from edge of the flange, spaced 2" apart.
5. Rough up the copper flange surface and clean the flange.
6. Apply the roofing membrane to the scupper flange and seal according to the roofing manufacturer's instructions.
7. Bolt the clamping ring on using the wrench provided. Do not to over-tighten.
8. Outside the wall, connection or sealing by others.
9. Adhere to the installation requirements as determined by the regulatory authorities for your region.