



B VENT FLAT GALVANIZED INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

1. Make certain that the hole in roof deck is the same size as the opening at the bottom of the B-Vent flashing.
2. If installing on an existing roof, clear any debris or materials that may prevent the B-Vent flange from laying flush against the deck.
3. Place the B-Vent on the roof deck and ensure that the metal flange is flush with roof surface.
4. The B-Vent flange must be secured to the roof deck with a minimum of 4 broad head fasteners screwed into a solid substrate. Fastening evenly spaced, 1" from edge of flange, is optimal.
5. Follow the roofing system manufacturer's installation instructions for installing and flashing the roofing membrane to the B-Vent flange.
6. Seal the flashing to the pipe with an appropriately sized storm collar.
7. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Visit the Menzie's Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzie's Metal Products

19370 60th Avenue, Surrey, BC V3S 3M2
800-665-8840 sales@menzies-metal.com
www.menzies-metal.com

More Than Just Metal

E. & O.E
01242014