



## SV50 INSTALLATION INSTRUCTIONS

### **Important: Read Instructions Before Installation.**

1. Before cutting the hole in the roof, ensure that there are no obstructions or trusses located beneath the vent location.
2. Match the size of the roof hole with the opening in the base of the vent.
3. Cut the hole.
4. Remove any nails that will prevent the vent flange from sliding into place under the shingles.
5. Slide the vent under the shingles. The exposed flange should lay on top of the shingles as shown; as if the flange were a shingle.
6. Install roofing material in accordance with proper roofing practices.
7. Using the pre-punched holes to fasten the vent to the substrate.
8. Waterproof the exposed fasteners with an appropriate sealant.
9. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at [www.menzies-metal.com](http://www.menzies-metal.com) or scan the QR code.

