



SPUN COPPER DECK DRAIN 2" DWV INSTALLATION INSTRUCTIONS

1. Cut an appropriate sized hole over the receiving drainpipe.
2. Remove any debris or material that may prevent the drain flange from laying flush on the deck.
3. Remove the strainer from the drain.
4. The flange must lay flush on the deck.
5. Secure the drain to the deck with a minimum of 3 broad-head fasteners.
6. Make certain that the decking material reaches the edge of drain bowl but does not go into the drain bowl.
7. Apply and secure the roofing material in accordance with the manufacturer's instructions.
8. Replace the strainer and tighten securely.
9. Under deck connection by others.
10. Adhere to installation requirements as determined by the regulatory authorities for your region.