

SPUN ALUMINUM STACK AND CAP INSTALLATION INSTRUCTIONS

Important: Read Instructions Before Installation.

- 1. Remove debris or materials that may prevent the pipe flashing flange from laying flush on the deck.
- 2. Lower the pipe flashing over the pipe and onto the roof deck ensuring that metal flange is flush with roof surface.
- 3. Secure the flashing flange to the roof deck using a minimum of 4 round head fasteners into solid substrate. Fastening evenly spaced, 1" from edge of flange, is optimal.
- 4. Follow roofing system manufacturer's installation instructions for installing and flashing roofing membrane to pipe flashing.
- 5. Place cap on top of the aluminum stack. Screw on to stack to secure. Do not penetrate pipe.
- 6. Adhere to the installation requirements as determined by the regulatory authorities for your region.

Visit the Menzies Metal Products' website for additional product information. Drawings, Specifications and Instructions are available for most products online at www.menzies-metal.com or scan the QR code.



Menzies Metal Products

More Than Just Metal